

## Aktuální orientační ceník náhradních dílů Alesis spare Monitory - 2018

(cena je orientační a při prodeji je počítána dle aktuálního kurzu USD, EUR nebo Libry)

Model	Part Number	Part Description	Value	Cena CZK
<b>Elevate 5</b>	20050037	Front Panel Moulding(Active)		115 CZK
(LAU8)	20050038	Front Panel Moulding(Passive)		115 CZK
(LAU8)	54290004	Front Panel Textured Overlay(Active)		109 CZK
(LAU8)	54290005	Front Panel Textured Overlay(Passive)		109 CZK
(LAU8)	13110006	PCB Assy, Power		569 CZK
(LAU8)	CR010528-	PCB Assy, Pre-Power Amp		684 CZK
(LAU8)	80010016	Tweeter, 3/4inch	4 Ohm	209 CZK
(LAU8)	80080007	Woofer, 5inch	4 Ohm	413 CZK
<b>Elevate 6</b>	54290008	Front Panel Textured Overlay(Passive)		105 CZK
(LAUA)	13030218	Power Transformer		564 CZK
(LAUA)	CR010641	PCB Assy, Power Amp-Pre Amp		902 CZK
(LAUA)	CR010643	PCB Assy, Standby		310 CZK
(LAUA)	80020032	Tweeter 1"	8 Ohm	172 CZK
(LAUA)	80120024	Woofer 6.5"	4 Ohm	548 CZK
<b>Gigamix4FX</b>	9-15-0378-A	Knob, Rotary, Cap, Large (Black)		101 CZK
(XP0)	9-15-0332-A	Knob, Rotary, Cap, Large (Blue)		101 CZK
(XP0)	PT1310622	Knob, Rotary, Cap, Small (Black)		101 CZK
(XP0)	9-15-0338-A	Knob, Rotary, Cap, Small (Blue)		101 CZK
(XP0)	9-15-0336-A	Knob, Rotary, Cap, Small (Green)		101 CZK
(XP0)	9-15-0337-A	Knob, Rotary, Cap, Small (Red)		101 CZK
(XP0)	9-15-0382-A	Knob, Rotary, Large, Grey, Less Cap		101 CZK
(XP0)	9-15-0380-A	Knob, Rotary, Small, Grey, Less Cap		101 CZK
(XP0)	PL1760510000	Knob, Slider, Main EQ		101 CZK
(XP0)	SW0000000017	Rotary Encoder, Effect		104 CZK
(XP0)	VR1150313201	Rotary Pot, Ch EQ	B50K CC	104 CZK
(XP0)	VR1110313201	Rotary Pot, Ch Level/Effect Return/2 Track Return/Main	A10K	104 CZK
(XP0)	VR1150313200	Rotary Pot, Ch Mon/Ch Effect	B50K	104 CZK
(XP0)	VR2110406000	Slide Pot, Main EQ	W100K	109 CZK
<b>Gigamix6FX</b>	9-15-0378-A	Knob, Rotary, Cap, Large (Black)		101 CZK
(XP1)	9-15-0332-A	Knob, Rotary, Cap, Large (Blue)		101 CZK
(XP1)	PT1310622	Knob, Rotary, Cap, Small (Black)		101 CZK
(XP1)	9-15-0338-A	Knob, Rotary, Cap, Small (Blue)		101 CZK
(XP1)	9-15-0336-A	Knob, Rotary, Cap, Small (Green)		101 CZK
(XP1)	9-15-0337-A	Knob, Rotary, Cap, Small (Red)		101 CZK
(XP1)	9-15-0382-A	Knob, Rotary, Large, Grey, Less Cap		101 CZK
(XP1)	9-15-0380-A	Knob, Rotary, Small, Grey, Less Cap		101 CZK
(XP1)	PL1760510000	Knob, Slider, Main EQ		101 CZK
(XP1)	SW0000000017	Rotary Encoder, Effect		104 CZK
(XP1)	VR1150313201	Rotary Pot, Ch EQ	B50K CC	104 CZK
(XP1)	VR1110313201	Rotary Pot, Ch Level/Effect Return/2 Track Return/Main	A10K	104 CZK
(XP1)	VR1150313200	Rotary Pot, Ch Mon/Ch Effect	B50K	104 CZK
(XP1)	VR2110406000	Slide Pot, Main EQ/Monitor EQ	W100K	119 CZK
<b>Gigamix8FX</b>	9-15-0378-A	Knob, Rotary, Cap, Large (Black)		104 CZK
(XP2)	9-15-0332-A	Knob, Rotary, Cap, Large (Blue)		104 CZK
(XP2)	PT1310622	Knob, Rotary, Cap, Small (Black)		104 CZK
(XP2)	9-15-0338-A	Knob, Rotary, Cap, Small (Blue)		104 CZK
(XP2)	9-15-0336-A	Knob, Rotary, Cap, Small (Green)		104 CZK
(XP2)	9-15-0337-A	Knob, Rotary, Cap, Small (Red)		104 CZK
(XP2)	9-15-0382-A	Knob, Rotary, Large, Grey, Less Cap		104 CZK
(XP2)	9-15-0380-A	Knob, Rotary, Small, Grey, Less Cap		104 CZK
(XP2)	PL1760510000	Knob, Slider, Main EQ		104 CZK
(XP2)	SW0000000017	Rotary Encoder, Effect		109 CZK
(XP2)	VR1150313201	Rotary Pot, Ch EQ	B50K CC	109 CZK
(XP2)	VR1110313201	Rotary Pot, Ch Level/Monitor Effect Return/Monitor Mix	A10K	109 CZK
(XP2)	VR1150313200	Rotary Pot, Ch Mon/Ch Effect	B50K	109 CZK
(XP2)	VR1210314202	Rotary Pot, Main Effect Return/Main Mix/ 2 Track Return	A10KX2	109 CZK
(XP2)	VR1150213201	Rotary Pot, Pan	B5K CC	109 CZK
(XP2)	VR2210406000	Slide Pot, Main EQ	W100KX2	119 CZK
(XP2)	VR2110406000	Slide Pot, Monitor EQ	W100K	119 CZK
<b>M1 Active 320USB</b>	IC0520200900	IC, Power Amplifier, TDA2009		119 CZK
(LAU0)	CR000709	PCB Assy, Amp/Pre/Input		744 CZK
(LAU0)	CR000711	PCB Assy, USB		420 CZK
(LAU0)	13030155	Power Transformer	115-230V	418 CZK
(LAU0)	15010343	Rotary Pot, Volume		101 CZK
(LAU0)	80010002	Tweeter 3/4"	4 Ohm	105 CZK
(LAU0)	80220003	Woofer 3"	4 Ohm	149 CZK
<b>M1 Active 520</b>	TWPC04A02101	PCB Assy, Amplifier		1 597 CZK
(AS7)	TF85046601YH	Power Transformer		783 CZK
(AS7)	VRR20302501	Rotary Pot, Volume	20KA	101 CZK

## Aktuální orientační ceník náhradních dílů Alesis spare Monitory - 2018

(cena je orientační a při prodeji je počítána dle aktuálního kurzu USD, EUR nebo Libry)

Model	Part Number	Part Description	Value	Cena CZK
(AS7)	OTSJ-050302R	Tweeter	4 Ohm	209 CZK
(AS7)	OTSK-040628R	Woofers	8 Ohm	618 CZK
<b>M1 Active</b>	20210086	Knob, Rotary		26 CZK
<b>520USB</b>	CR001082	PCB Assy, Power Amp		600 CZK
(LAU1)	CR001086	PCB Assy, Pre-Amp		573 CZK
(LAU1)	CR001088	PCB Assy, USB		107 CZK
(LAU1)	13030183-A	Power Transformer	115-230V	544 CZK
(LAU1)	15010385	Rotary Pot, Volume		109 CZK
(LAU1)	80020026	Tweeter	6 ohm	170 CZK
(LAU1)	80090006	Woofers	4 ohm	386 CZK
(LAU1)	40030015	Jack, 1/4", Input		109 CZK
<b>M1 Active 620</b>	TWPC05A00401	PCB Assy, Amplifier		1 278 CZK
(AS6)	OTYNA05005	PCB Assy, Power Supply		1 217 CZK
(AS6)	VRR20302501	Rotary Pot, Volume	20KA	109 CZK
(AS6)	OTFR94B4-01T	Tweeter	4 Ohm	209 CZK
(AS6)	OTFR165B8-12M	Woofers	8 Ohm	1 477 CZK
<b>M1 Active MK2</b>	9-79-0255-C	PCB Assy, Amplifier		1 318 CZK
(8M)	9-79-B601	PCB Assy, Power Supply		1 557 CZK
(8M)	0-09-0009	Rotary Pot, Volume	10KA	109 CZK
(8M)	7-02-0028	Tweeter	4 Ohm	422 CZK
(8M)	OTFR165B8-12M	Woofers	8 Ohm	1 477 CZK
<b>M1 Active Mk3</b>	13030226	Power Transformer		666 CZK
(LAUJ)	CR011168	PCB Assy, Power		103 CZK
(LAUJ)	CR011169	PCB Assy, Amplifier		996 CZK
(LAUJ)	80010024	Tweeter, 3/4 inch	8 Ohm	164 CZK
(LAUJ)	80080011	Woofers, 5 inch	4 Ohm	685 CZK
<b>Monitor 1 MK2</b>	8-20-0064	PCB Assy, Crossover Network		251 CZK
(1N)	7-02-0028	Tweeter	4 Ohm	422 CZK
	7-02-0029	Woofers	4 Ohm	561 CZK
<b>PA System in a Box</b>	020600149	Button, Push, Media Player		26 CZK
(LPA4/6)	020600007	Crossover		151 CZK
(LPA4/6)	050300013	Fan		109 CZK
(LPA4/6)	010500008	Grill		209 CZK
(LPA4/6)	080700009	Microphone		142 CZK
(LPA4/6)	080900012	Microphone Cable		151 CZK
(LPA4/6)	050300035	PCB Assy, Output		149 CZK
(LPA4/6)	050300025	PCB Assy, Power Amp		377 CZK
(LPA4/6)	050300018	PCB Assy, Pre-Amp		974 CZK
(LPA4/6)	050300006	PCB Assy, USB Media Player		462 CZK
(LPA4/6)	050300128	Power Transformer		536 CZK
(LPA4/6)	081000003	Stand		974 CZK
(LPA4/6)	020300015	Tweeter		184 CZK
(LPA4/6)	020300005	Woofers		234 CZK
<b>ProActive 2.0</b>	IC0020040200	IC, Power Amplifier, STK402-090		293 CZK
(AS0)	TT2210010300	Power Transformer		893 CZK
(AS0)	SK2030300000	Woofers		401 CZK
<b>Prolinear 720</b>	9-79-0294	PCB Assy, Power Supply		2 318 CZK
<b>&amp; 720 DSP</b>	7-02-0031	Tweeter		1 597 CZK
(AS4) (AS1)	7-02-0034	Woofers		2 087 CZK
<b>Prolinear 820</b>	9-79-0294	PCB Assy, Power Supply		2 318 CZK
<b>&amp; 820 DSP</b>	7-02-0031	Tweeter		1 597 CZK
(AS5) (AS3)	7-02-0035	Woofers		2 241 CZK
<b>ProVenue 12</b>	307-70240	PCB Assy, Crossover Network		824 CZK
(AL0)	108-80150	Jack, 1/4" with housing		101 CZK
(AL0)	TP202039-2	Tweeter, Compression Driver	16 Ohm	453 CZK
(AL0)	TP212034-11	Woofers	8 Ohm	1 597 CZK
<b>ProVenue 15</b>	307-70240	PCB Assy, Crossover Network		824 CZK
(AL1)	108-80150	Jack, 1/4" with housing		101 CZK
(AL1)	TP202039-2	Tweeter, Compression Driver	16 Ohm	453 CZK
(AL1)	TP215026-3	Woofers	8 Ohm	1 964 CZK
<b>Transactive</b>	14040177	IC, Power Amp, TDA7294		133 CZK
<b>Drummer</b>	20210024	Knob, Rotary		101 CZK
(LGK8)	60050001	Lamp, Tweeter Protection		101 CZK
(LGK8)	CR001097	PCB Assy, Power/Amp		909 CZK
(LGK8)	CR001099	PCB Assy, Pre-Amp		605 CZK
(LGK8)	CR001101	PCB Assy, Rear		896 CZK
(LGK8)	CR001103	PCB Assy, iPod Docking Connector		237 CZK
(LGK8)	13030186	Power Transformer		1 226 CZK
(LGK8)	15010383	Rotary Pot, EQ	B50K	119 CZK

## Aktuální orientační ceník náhradních dílů Alesis spare Monitory - 2018

(cena je orientační a při prodeji je počítána dle aktuálního kurzu USD, EUR nebo Libry)

Model	Part Number	Part Description	Value	Cena CZK
(LGK8)	15010382	Rotary Pot, Master/iPOD-Aux	A10K	119 CZK
(LGK8)	80010017	Tweeter		180 CZK
(LGK8)	80150040	Woofer		1 377 CZK
<b>Transactive</b>	60100011	Antenna		119 CZK
<b>Drummer Wireless</b>	14040177	IC, Power Amp, TDA7294		133 CZK
(LGK9)	20210024	Knob, Rotary		101 CZK
(LGK9)	CR001101	PCB Assy, Rear		896 CZK
(LGK9)	13030212	Power Transformer		1 120 CZK
(LGK9)	15010383	Rotary Pot, EQ	B50K	119 CZK
(LGK9)	15010382	Rotary Pot, Master/Wireless-Aux	A10K	119 CZK
(LGK9)	80020030	Tweeter		255 CZK
(LGK9)	80150040	Woofer		1 377 CZK
<b>Transactive Live</b>	60190079	Battery, Rechargeable		933 CZK
(LGAM)	20210039	Knob, Rotary		119 CZK
(LGAM)	CR000982	PCB Assy, iPod Docking Connector		296 CZK
(LGAM)	CR001057	PCB Assy, Power		373 CZK
(LGAM)	CR001053	PCB Assy, Power Amp		172 CZK
(LGAM)	CR001055	PCB Assy, Pre-Amp		445 CZK
(LGAM)	13030141	Power Transformer	115-230V	393 CZK
(LGAM)	15010161	Rotary Pot, iPod-Aux	10KAX2	119 CZK
(LGAM)	15010221	Rotary Pot, Mic/Instrument/Master	10KA	119 CZK
(LGAM)	80010007	Tweeter	4 ohm	149 CZK
(LGAM)	80120015	Woofer	4 ohm	205 CZK
<b>Transactive</b>	60190001	Battery, Rechargeable		1 367 CZK
<b>Mobile</b>	14040179	IC, Power Amp, TDA7360		110 CZK
<b>Mobile</b>	20210039	Knob, Rotary		101 CZK
<b>Mobile</b>	CR000462	PCB Assy, Crossover		293 CZK
<b>Mobile</b>	CR000456	PCB Assy, iPod Docking Connector		-
<b>Mobile</b>	CR000458	PCB Assy, Power Amp		742 CZK
<b>Mobile</b>	CR000457	PCB Assy, Pre-Amp		701 CZK
<b>Mobile</b>	13030141	Power Transformer	115-230V	393 CZK
<b>Mobile</b>	15010161	Rotary Pot, iPod-Aux	10KAX2	101 CZK
<b>Mobile</b>	15010221	Rotary Pot, Mic/Instrument/Master	10KA	101 CZK
<b>Mobile</b>	80020021	Tweeter		553 CZK
<b>Mobile</b>	80130025	Woofer		335 CZK
<b>Transactive</b>	60190079	Battery, Rechargeable		933 CZK
<b>Wireless</b>	20210118	Knob, Rotary		101 CZK
(LGAC)	CR010379	PCB Assy, Power		402 CZK
(LGAC)	CR010337	PCB Assy, Power Amp		209 CZK
(LGAC)	CR010346	PCB Assy, Pre-Amp-BT Module		808 CZK
(LGAC)	13030200	Power Transformer	115-230V	402 CZK
(LGAC)	15010459	Rotary Pot, Mic/Aux/Master	10KA	101 CZK
(LGAC)	30150084	Telescopic Handle		352 CZK
(LGAC)	80010012	Tweeter		149 CZK
(LGAC)	10520106	Wheel Assy		109 CZK
(LGAC)	80130031	Woofer		370 CZK
<b>Transactive</b>	20210118	Knob, Rotary		101 CZK
<b>Wireless 2</b>	CR011003	PCB Assy, LED Display		203 CZK
(LGAF)	CR011001	PCB Assy, LED Drive		229 CZK
(LGAF)	CR010999	PCB Assy, Power-Power Amp-Controller		477 CZK
(LGAF)	13110029	PCB Assy, Power Supply		462 CZK
(LGAF)	CR010997	PCB Assy, Pre Amp		862 CZK
(LGAF)	30150142	Telescopic Handle		322 CZK
(LGAF)	80320001	Tweeter		139 CZK
(LGAF)	10520106	Wheel Assy		129 CZK
(LGAF)	80130037	Woofer		388 CZK
<b>Transactive 400</b>	HE00234	Fan, 12V		152 CZK
<b>Transactive 400</b>	HC00125	Jack, 1/4"		101 CZK
<b>Transactive 400</b>	HC00126	Jack, XLR		101 CZK
<b>Transactive 400</b>	NI02372	Knob, Rotary		101 CZK
<b>Transactive 400</b>	HK15707	PCB Assy, Mixer-EQ		306 CZK
<b>Transactive 400</b>	HK15706	PCB Assy, Input-Output		1 035 CZK
<b>Transactive 400</b>	HK14380	PCB Assy, Power Supply-Power Amp		2 597 CZK
<b>Transactive 400</b>	RC00986	Rotary Pot, EQ	B50KX2 CC	101 CZK
<b>Transactive 400</b>	RC00987	Rotary Pot, Master Volume/Headphone Volume	W50KX2	101 CZK
<b>Transactive 400</b>	HI00030	Switch, Power		101 CZK
<b>Transactive 400</b>	HG00490	Tweeter	8 Ohm	431 CZK
<b>Transactive 400</b>	HK14300	Woofer 12inch	8 Ohm	1 053 CZK